

FT-897D S Meter calibration

Meter	21MHz CW			145MHz CW			145MHz FM		
	dBm	dB	dB	dBm	dB	dB	dBm	dB	dB
S1	-106.0	0.0	-21.3	-116.0	0.0	-22.5	-113.0	0.0	-13.7
		0.2			0.4			1.5	
S2	-105.8	0.2	-21.1	-115.6	0.4	-22.1	-111.5	1.5	-12.2
		0.5			0.6			1.9	
S3	-105.3	0.7	-20.6	-115.0	1.0	-21.5	-109.6	3.4	-10.3
		0.6			0.5			1.9	
S4	-104.7	1.3	-20.0	-114.5	1.5	-21.0	-107.7	5.3	-8.4
		0.8			1.0			1.8	
S5	-103.9	2.1	-19.2	-113.5	2.5	-20.0	-105.9	7.1	-6.6
		1.2			1.2			2.4	
S6	-102.7	3.3	-18.0	-112.3	3.7	-18.8	-103.5	9.5	-4.2
		2.9			3.1			1.4	
S7	-99.8	6.2	-15.1	-109.2	6.8	-15.7	-102.1	10.9	-2.8
		6.8			7.0			1.3	
S8	-93.0	13.0	-8.3	-102.2	13.8	-8.7	-100.8	12.2	-1.5
		8.3			8.7			1.5	
S9	-84.7	21.3	0.0	-93.5	22.5	0.0	-99.3	13.7	0.0
		8.7			8.3			1.6	
S9+	-76.0	30.0	8.7	-85.2	30.8	8.3	-97.7	15.3	1.6
		17.6			16.9			5.5	
S9++	-58.4	47.6	26.3	-68.3	47.7	25.2	-92.2	20.8	7.1